# DART SERVICE INSTRUCTION

TO AMEND OWNER'S & OVERHAUL PROCEDURE MANUAL O&OPM-C10 REV. 4 OR LATER APPROVED REVISIONS

#### 1.0 PURPOSE

The purpose of this DART Service Instruction (DSI) is to provide instructions for installing the DSI 9835-011 Release Knob Guard Kit. The Release Knob Guard Kit can be installed on any C10 Keeper Remote Cargo Hook or C10-K Keeperless Remote Cargo Hook.


#### 2.0 PROCEDURE (APPLICABLE TO C10/C10-K)

- 2.1 Remove and discard the 600.1309 Label or 600.1309-A Label and C2-14-2 Label Rivets, if installed. Proceed to Section 2.2 if the Label and Label Rivets are not installed on the Remote Cargo Hook. The information on the Label (P/N, S/N, and Capacity) must be engraved using an engraving pen, or metal stamped, on the C10-1 Side Plate Solenoid Side or C10-2 Side Plate MRK. The Label information should not be engraved or metal stamped on the lateral surfaces of the Side Plate Solenoid Side or the Side Plate MRK.
- 2.2 Remove and discard the MS21044N6 Nuts, AN960-616L Washers, and AN6-31A Bolts from the Remote Cargo Hook as shown in Figure 1.
- 2.3 Apply Rust Inhibitor LPS 3 on grip and threads of the AN6-33A Bolts.
- 2.4 Install the C10-100 Release Knob Guard onto the Remote Cargo Hook using the AN6-33A Bolts, NAS1149F0663P Washers, and MS21044N6 Nuts as shown in Figure 2.
- 2.5 Torque the MS21044N6 Nuts to 160-190 in-lbs (18.0-21.4 N-m).

#### 3.0 PARTS LIST


QTY -011	PART NUMBER	DESCRIPTION RELEASE KNOB GUARD KIT	
Х	DSI 9835-011		
1	C10-100	RELEASE KNOB GUARD	
2	AN6-33A	BOLT	
2	MS21044N6	NUT	
4	NAS1149F0663P	WASHER	

Α	NEW ISSUE			2620-530	KPT	
REV.	DESCRIPTION			ECN#	BY	
DESIG	N	KPT	DART AEROSPACE LTD			
DRAW	N	KPT	HAWKESBURY, ONTARIO, CANADA			
CHEC	KED	РМ	DRAWING NO.		REV. A	
MFG. A	NPPR.	N/A	DSI 9835	SHEET 1 OF 3		
APPRO	OVED	a	TITLE	SCALE [		
DATE 2/27/2020			C10/C10-K RELEASE KNOB GUARD INSTALLATION	NTS L		
		/2020	COPYRIGHT © 2020 BY DART AEROSPACE LTD  THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS  NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT			



### FIGURE 1: REMOTE CARGO HOOK HARDWARE REMOVAL

(ELECTRICAL WIRES NOT SHOWN FOR CLARITY)



## **FIGURE 2: RELEASE KNOB GUARD INSTALLATION**

(ELECTRICAL WIRES NOT SHOWN FOR CLARITY)

DESIGN	KPT	DART AEROSPACE LTD		
DRAWN	KPT	HAWKESBURY, ONTARIO, CANADA		
CHECKED	PM	DRAWING NO. REV.	. A	
MFG. APPR.	N/A	DSI 9835 SHEET 2 0	F 3	
APPROVED	41	TITLE SCALE SCALE	<u></u>	
DATE 2/27/2020		C10/C10-K RELEASE KNOB GUARD INSTALLATION NTS	<b>#</b>	
		COPYRIGHT © 2020 BY DART AEROSPACE LTD		
		THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS		
		NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT		

# **4.0 WEIGHT AND BALANCE**

The installation of the Release Knob Guard Kit has negligible affect on the aircraft's weight and balance.

## **5.0 MAINTENANCE**

The Release Knob Guard must be checked for excessive wear, abuse, or damage prior to use. Refer to O&OPM-C10 for additional inspection and maintenance procedures.

DESIGN	KPT	DART AEROSPACE LTD		
DRAWN	KPT	HAWKESBURY, ONTARIO, CANADA		
CHECKED	PM	DRAWING NO.	REV	/. A
MFG. APPR.	N/A	DSI 9835	SHEET 3 C	OF 3
APPROVED	4'	TITLE C10/C10-K	SCALE	<b>(</b>
DATE 2/27/2020		RELEASE KNOB GUARD INSTALLATION	NTS T	\$
		COPYRIGHT © 2020 BY DART AEROSPACE LTD  THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS  NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT		